

Contact: Michelle Lennard
Sears Corporate Communications
416.435.5711
mlennar@sears.ca

**Sears Canada Advised of a Potential Safety Hazard
Relating to Certain Frigidaire® Electric Smoothtop Cooktops and Slide-in
Ranges and Electrolux ICON® Electric Smoothtop Cooktops**

Toronto, ON –October 21, 2010 - Sears Canada has been advised by the Electrolux Canada Corp. of a potential safety hazard relating to certain Frigidaire® electric smoothtop cooktops and slide-in ranges, and Electrolux ICON® electric smoothtop cooktops, all with rotary knobs and digital displays. It has been discovered that liquids pooling under the control knobs can cause a surface heating element to turn on unexpectedly, heat to temperatures other than expected and then not turn off, posing a risk of fire and burn hazards to consumers

The ranges were sold through Sears Canada retail stores, online at www.sears.ca, and through the Sears Canada catalogue between January 2005 and October 2010. The affected model numbers and corresponding Sears item numbers are as follows:

MFG #	Serial Number	Sears Stock #
CGLES389EB	NF501xxxxx-NF652xxxxx	29669
CGLES389ES	NF501xxxxx-NF652xxxxx	29662
CGLES389FB	NF601xxxxx-NF852xxxxx	29479
CGLES389FS	NF601xxxxx-NF952xxxxx	29472
CPLES399EC	NF501xxxxx-NF952xxxxx	28553
E30EC65ESS	NF501xxxxx-NF045xxxxx	28741
PLEC30S9EC	NF501xxxxx-NF952xxxxx	28733
PLEC36S9EC	NF501xxxxx-NF952xxxxx	28793

The model number can be found inside the oven door on the left side of the unit or on the underside surface on the cooktop models.

In the interest of consumer safety, Sears Canada urges customers who own an affected range to cease

use immediately and unplug the range from the electrical outlet or power off the cooktops at the circuit breaker.

Sears Customers should contact Electrolux at 1-800-777-9241, Monday through Saturday between 8:00 AM and 5:00 PM ET., for information on how to obtain a free repair kit. Alternatively, customers can visit the company's websites at www.cooktoprecall.ca or www.rappelcuisinieresurfacelisse.ca (for Electrolux ICON Models) or www.smoothtoprangerecall.ca or www.rappelcuisinieresurfacelisse.ca (for Frigidaire Models).

Sears Canada will be posting signs in all of its retail stores to advise customers of this safety hazard. Sears Canada is bringing this matter to the public's attention in the interest of consumer safety and apologizes to its customers for any inconvenience.

Sears Canada is a multi-channel retailer with a network of 197 corporate stores, 241 hometown dealer stores, 31 home improvement showrooms, over 1,800 catalogue merchandise pick-up locations, 108 Sears Travel offices and a nationwide home maintenance, repair, and installation network. The Company also publishes Canada's most extensive general merchandise catalogue and offers shopping online at www.sears.ca.